

PUROXI WATER SERIES

UNDERSTANDING TURBIDITY

What Cloudy Water Can—and Cannot—Tell Us

PWS-010



Turbidity Is an Optical Measurement

Turbidity describes the relative clarity of water by measuring how suspended and dissolved material scatters light. A higher reading means that more light is being scattered under the conditions and method used.

The measurement does not identify the particles, determine their mass or prove whether the water is safe. It is best understood as a sensitive indicator that something affecting optical clarity is present or changing.

- Clay, silt, organic matter, plankton, microorganisms, precipitated minerals and colour can influence the result.
- Very different mixtures can produce similar turbidity readings.
- The same water may produce different results when instruments, light sources or methods differ.

PUROXI INSIGHT Turbidity tells us how water interacts with light—not exactly what is suspended in it.

CHAPTER 2

What Makes Water Turbid

Particles enter water through erosion, storm runoff, construction, wastewater, disturbed sediment, biological growth and treatment processes. Particles may also form within water when minerals precipitate or microorganisms multiply.

Particle size, shape, colour and refractive properties affect light scattering. A small number of highly scattering particles may produce a strong reading, while heavier particles may settle quickly and be underrepresented if the sample is handled poorly.

- Inorganic: clay, silt, metal oxides and mineral precipitates.
- Organic: plant debris, finely divided organic matter and wastewater solids.
- Biological: algae, plankton, bacteria and other microorganisms.
- Measurement interference: air or gas bubbles, scratched cells, fingerprints and stray light.

PUROXI INSIGHT Cloudiness is an observation. Turbidity is a method-based measurement of light scattering.

CHAPTER 3

How Turbidity Is Measured and Reported

Most turbidity instruments direct light into a sample and measure light scattered at one or more angles. Nephelometric methods emphasize light detected near 90 degrees to the incident beam.

Results may be reported as NTU, FNU or other method-specific units. These units are not always interchangeable because instrument geometry, wavelength and detector design influence the response.

Reported unit	General meaning
NTU	Nephelometric turbidity unit; commonly associated with white-light methods.
FNU	Formazin nephelometric unit; commonly associated with near-infrared ISO methods.
FAU or AU	Attenuation-based units that depend on the method and instrument.
Secchi depth	A water-clarity observation, not a direct turbidity-unit conversion.

PUROXI INSIGHT Always record the unit, instrument and method—not only the number.

CHAPTER 4

Sampling and Instrument Practice Matter

Turbidity can change between the water body and the instrument. Particles settle, gas bubbles form or disappear, and biological material changes with time. A representative sample and consistent technique are essential.

For online instruments, fouling, window coating, bubbles and calibration drift can look like real process change. Maintenance records should be reviewed alongside the data.

- Use clean, unscratched sample cells and handle them by the top.
- Mix gently when the method requires a representative suspended sample; do not create bubbles.
- Measure promptly and record location, depth, time, weather and flow conditions.
- Calibrate and verify the instrument with appropriate standards.
- Compare trends only when methods and sampling conditions are reasonably consistent.

PUROXI INSIGHT A precise display cannot correct an unrepresentative sample or a dirty optical surface.

CHAPTER 5

Turbidity Is Not the Same as TSS Colour or Clarity

Related measurements describe different properties. Total suspended solids, or TSS, measures the dry mass of material retained by a specified filter. True colour is associated with dissolved substances after suspended material is removed. Visual clarity depends on light, depth, background and the observer.

Turbidity and TSS may correlate within one stable source, but a universal conversion is unreliable because particles scatter light differently.

Measurement	What it primarily describes
Turbidity	Light scattered by material in the water.
TSS	Mass of filterable suspended solids per volume.
Colour	Optical colour from dissolved and suspended substances, depending on method.
Secchi depth	Field visibility through a water column.
Transparency	Light transmission through a sample or water column.

PUROXI INSIGHT Related indicators can move together, but they do not measure the same thing.

CHAPTER 6

Source Water Storms and Erosion

Rainfall, snowmelt, bank erosion, wildfire disturbance and construction can rapidly increase source-water turbidity. The same event may also transport nutrients, organic matter, microorganisms and contaminants attached to particles.

Turbidity should be interpreted with streamflow, weather and land-use information. Comparing readings at different flows or locations without context can create false conclusions.

- Establish normal seasonal ranges before defining alerts.
- Monitor upstream and downstream when identifying a source.
- Record rainfall and flow conditions with each field measurement.
- Investigate sudden changes even when the water later appears clear.

PUROXI INSIGHT A turbidity spike is an early warning of change—not a complete diagnosis of its cause.

CHAPTER 7

Drinking Water Filtration and Disinfection

In drinking-water treatment, turbidity is an important operational indicator. Particles can shelter microorganisms, increase disinfectant demand and indicate inadequate coagulation, clarification or filtration.

Low filtered-water turbidity supports confidence that particle-removal barriers are operating effectively, but it does not directly measure pathogens. Applicable regulatory limits and monitoring requirements depend on the jurisdiction and treatment process.

- Track raw, settled and filtered water separately.
- Use individual-filter monitoring where required or operationally valuable.
- Respond to upward trends before a compliance threshold is reached.
- Interpret turbidity with disinfectant residual, contact time and microbial monitoring.

PUROXI INSIGHT Clear water is not proof of safety, but rising filtered-water turbidity can warn that a protective barrier is weakening.

CHAPTER 8

Wastewater and Industrial Process Water

In wastewater, turbidity can help reveal solids carryover, clarifier upset, filtration performance or changing influent conditions. In industrial systems, it may indicate contamination, precipitation, corrosion products, process solids or membrane pretreatment problems.

The reading must be tied to a defined sampling point and operating condition. Colour, bubbles and unusual particle characteristics may affect optical instruments differently.

- Trend turbidity with TSS, flow and process loading.
- Confirm unexpected readings with inspection and laboratory testing.
- Use alarms as prompts for investigation, not as automatic identification of the cause.
- Select instruments for the expected range, colour and particle type.

PUROXI INSIGHT Operational value comes from connecting a turbidity change to the process that produced it.

CHAPTER 9

Aquaculture Lakes Ponds and Reservoirs

Turbidity can reduce light penetration, change the depth of photosynthesis, affect feeding behaviour and alter habitat. Mineral turbidity, planktonic turbidity and organic turbidity may have very different biological meanings.

In aquaculture, a single universal target is inappropriate. Species, life stage, system design, particle composition and duration of exposure all matter. Secchi depth, TSS, chlorophyll, dissolved oxygen and microscopy may be needed to understand the condition.

- Measure at consistent depths and times of day.
- Distinguish sediment disturbance from an algae bloom.
- Check gills, filters, screens and settling zones when solids increase.
- Interpret the reading with temperature and dissolved oxygen.

PUROXI INSIGHT The cause and duration of turbidity matter as much as the number.

CHAPTER 10

Algae Cyanobacteria and Biological Turbidity

Algae and cyanobacteria can raise turbidity, but turbidity cannot identify the organisms or determine whether toxins are present. A bloom may also create strong daily changes in dissolved oxygen and pH that a turbidity meter does not measure.

Microscopy, chlorophyll or phycocyanin measurements, toxin analysis and field observation may be required when biological growth is suspected.

- Do not treat turbidity as a direct algae count.
- Do not infer toxin concentration from appearance or NTU alone.
- Record surface accumulations separately from mixed-water readings.
- Use consistent locations because wind can concentrate floating organisms.

PUROXI INSIGHT Turbidity can reveal that optical conditions changed; it cannot name the organism responsible.

CHAPTER 11

Light Habitat and Aquatic Effects

Suspended particles reduce the distance light penetrates through water. This can limit submerged plant growth and shift where photosynthesis occurs. Deposited sediment can cover habitat, spawning areas and benthic communities.

Fine particles can also affect some fish and invertebrates through gill irritation, reduced feeding visibility or changes in food webs. Effects depend on concentration, particle type and exposure time.

- Short storm pulses and chronic turbidity should be evaluated differently.
- Deposited sediment may remain important after the water column clears.
- Natural background conditions vary between watersheds.
- Ecological assessment requires more than one optical measurement.

PUROXI INSIGHT Turbidity describes the water column; sediment deposition can continue affecting the ecosystem afterward.

CHAPTER 12

Treatment Follows a Sequence

Particles are commonly managed through a treatment train rather than one device. The correct sequence depends on particle size, charge, density, organic content, flow and the required finished-water quality.

Treatment step	Primary purpose
Source control	Reduce erosion, runoff or process solids before they enter the water.
Coagulation and flocculation	Destabilize small particles and form larger flocs.
Sedimentation or flotation	Separate particles by settling or controlled flotation.
Filtration	Remove remaining particles through media, screens or membranes.
Sludge management	Handle the solids removed from the water.
Verification	Confirm performance through turbidity and supporting tests.

PUROXI INSIGHT Treatment succeeds when the complete solids pathway is understood—from entry to removal and disposal.

CHAPTER 13

Aeration Nano Bubbles and Turbidity

Aeration and Puroxi Nano Bubble Nozzles can improve gas transfer, circulation and oxygen distribution when correctly designed. They do not directly filter suspended particles from water.

Circulation may temporarily increase measured turbidity by resuspending settled material. Gas bubbles can also scatter light and interfere with optical measurements if sampling is too close to the discharge or before bubbles dissipate.

- Choose sampling points away from visible gas entrainment unless that zone is intentionally being studied.
- Allow a representative sample to release entrained bubbles without allowing solids to settle excessively.
- Use filtration, clarification or solids separation when particle removal is the objective.
- Evaluate oxygen improvement and solids management as connected but separate functions.

PUROXI INSIGHT Mixing can reveal particles that were already present; a temporary rise does not necessarily mean new contamination.

CHAPTER 14

Monitoring Trends and Setting Alerts

One reading is a snapshot. A well-designed monitoring program establishes normal ranges by location, season, depth, weather and operating condition. Alerts should be linked to investigation and response steps.

Online sensors provide valuable continuity, while grab samples and laboratory measurements help verify unusual results and identify causes.

- Define the purpose of each monitoring point.
- Use the same method when evaluating long-term trends.
- Record cleaning, calibration and maintenance events.
- Set warning and action levels from the application, regulations and baseline data.
- Review related measurements before changing treatment.

PUROXI INSIGHT The strongest turbidity program combines consistent methods, context and a defined response to change.

CHAPTER 15

Common Turbidity Myths

Turbidity is valuable because it responds quickly to many changes, but that sensitivity also makes oversimplification dangerous.

Myth	More accurate interpretation
Clear water is safe	Many microorganisms and dissolved contaminants are invisible.
High turbidity identifies the contaminant	The reading does not identify particle composition or source.
Turbidity equals TSS	One is optical; the other is a mass measurement.
All NTU readings are directly comparable	Instrument method, wavelength and geometry can affect results.
Aeration removes turbidity	Aeration transfers gas; particle removal requires a suitable separation process.
One target fits every application	Acceptable conditions depend on use, biology, treatment and regulation.

PUROXI INSIGHT Turbidity is a clue about change—not a complete water-quality verdict.

CHAPTER 16

A Practical Turbidity Decision Framework

Begin with the reason for measuring. Then use the result to guide investigation, treatment and verification rather than treating it as a stand-alone answer.

- Define the application and the consequence of increased turbidity.
- Confirm the instrument, method, unit, range and calibration.
- Collect a representative sample and record location, depth, flow and weather.
- Identify likely mineral, organic, biological or process sources.
- Measure supporting parameters such as TSS, colour, chlorophyll, dissolved oxygen or microbial indicators as appropriate.
- Choose source control and separation treatment that match the particles.
- Verify improvement using the same measurement basis and consistent sampling conditions.

PUROXI INSIGHT Understanding Always Comes Before Recommendation.

KEY LESSONS

- Turbidity is an optical measurement of light scattering.
- It does not identify particles, directly measure their mass or prove water safety.
- NTU, FNU and other units are method-specific and should not be treated as universally interchangeable.
- Turbidity is not the same as TSS, colour, transparency or Secchi depth.
- Particles can interfere with treatment, light penetration, habitat and equipment.
- Aeration and nano bubbles do not directly remove suspended particles.
- Consistent sampling and trend interpretation are more useful than isolated numbers.

The number becomes useful only when the method, source and application are understood.

TECHNICAL REFERENCES

- U.S. Geological Survey. Turbidity and Water. Water Science School. <https://www.usgs.gov/water-science-school/science/turbidity-and-water>
- U.S. Geological Survey. National Field Manual Chapter A6 Section 6.7 Turbidity. <https://pubs.usgs.gov/publication/twri09A6.7>
- World Health Organization. Water Quality and Health Review of Turbidity. WHO/FWC/WSH/17.01. <https://www.who.int/publications/i/item/WHO-FWC-WSH-17.01>
- World Health Organization. Guidelines for Drinking-water Quality Fourth Edition Incorporating the Third Addendum. 2026.
- U.S. Environmental Protection Agency. Surface Water Treatment Rule Turbidity Guidance Manual.
- U.S. Environmental Protection Agency. Turbidity Provisions. <https://www.epa.gov/dwreginfo/turbidity-provisions>
- Food and Agriculture Organization of the United Nations. Site Selection for Aquaculture Physical Features of Water.

Regulatory limits and monitoring requirements vary by jurisdiction and treatment process. Current local requirements should be confirmed before establishing compliance targets.

ABOUT THE PUROXI WATER SERIES

The Puroxi Water Series is an educational publication created to improve understanding of water through science, practical experience and thoughtful discussion. Each edition focuses on one important measurement or process and explains what it means, what it does not mean and how it should be interpreted in real applications.

PWS-010 — Understanding Turbidity continues the series by connecting optical clarity with particles, biological activity, treatment performance, aquatic systems and responsible monitoring.

UNDERSTANDING ALWAYS COMES BEFORE RECOMMENDATION.

Puroxi Pure Water Global Inc.
British Columbia, Canada
www.puroxi.com
info@puroxi.com